

Thanks for purchasing from MK Machining!

You will need a 3/32" Allen wrench to complete the assembly.

To install our parallax or illumination wheel you will first need to remove the single Allen head screw. Be careful not to let the factory installed washer fall out of its slot at this point. Spread the wheel open just enough to place it onto the parallax or illumination knob on your optic. Carefully align the grooves or features of our wheel to the matching features on the knob. Then all you need to do is reinstall the Allen screw finger tight, roughly 8in/lbs. **Do Not Overtighten.**

There Will be a gap when fully installed. Do not try to close the gap when installing or damage to the wheel may occur.

Note: Do not be afraid to spread open the parallax wheel. These are made from a very durable nylon that will stretch more than enough without damage and return to its original shape.